

Set Defaults Bar Code



Return to Factory Defaults

Enter Key Bar Code (Carriage Return/Line Feed)

Add an Enter key after scanned data.



Enter Key (Carriage Return/Line Feed)

Tab Key Bar Code

Add a Tab key after scanned data.



Tab Key

USB Caps Lock Override



USB Override Caps Lock Key (Enable)



*USB Do Not Override Caps Lock Key (Disable)